





AG950 100mm angle grinder part list

No.	Part list	No.	Part list
1	Down flange	26	Bearing 607Z
2	Out flange	27	bearing bush
3	Guard	28	Wind guide
4	screw	29	Screw
5	Front cover	30	Stator
6	Spindle	31	Housing
7	Dust cover	32	Brush holder
8	Bearing 6201RS	33	Carbon brush
9	Circlip	34	Brush holder spring
10	Big gear	35	Switch
11	Needle bearing HK0810	36	Cable press board
12	screw	37	screw
13	Gear box	38	Rear cover
14	Spindle locking pin	39	Cable sleeve
15	Spring	40	Cable
16	Spring locking button	43	Capacitor
17	Nut	44	Cable cap
18	Pinion	45	Spanner
19	Bearing holder	46	screw
20	Bearing 608Z	47	Washer
21	Washer	48	Side handle
22	Bearing press board	49	Screw
23	Circlip		
24	Rotor		
25	Anti-Dust ring		



AG950 125mm angle grinder part list

No.	Part list	No.	Part list
1	Down flange	26	Washer
2	Out flange	27	Bearing 607Z
3	Guard	28	Bearing bush
4	screw	29	Wind guide
5	Front cover	30	Screw
6	Spindle	31	Stator
7	Dust cover	32	Housing
8	Bearing 6201RS	33	Brush holder
9	Circlip	34	Carbon brush
10	Big gear	35	Brush holder spring
11	Needle bearing HK0810	36	Switch
12	screw	37	Cable press board
13	Gear box	38	screw
14	Spindle locking pin	39	Spring
15	Spring	40	Switch trigger
16	Spring locking button	41	Switch push pole
17	Nut	42	Rear cover
18	Pinion	43	Cable sleeve
19	Bearing holder	44	Cable
20	Bearing 608Z	49	screw
21	Washer	50	Cable cap
22	Bearing press board	51	spanner
23	Circlip	52	Screw
24	Rotor	53	Side handle
25	Anti-Dust ring		