


MS1600



| NO. | DESCRIPTION                 | NO. | DESCRIPTION          |
|-----|-----------------------------|-----|----------------------|
| 1   | BASE                        | 52  | SCREW M6X20          |
| 2   | FLAT WASHER                 | 53  | BELT                 |
| 3   | HEXAGON LOCK NUT M8         | 54  | BELT COVER           |
| 4   | STAINLESS STEEL RULER       | 55  | SCREW M5X43          |
| 5   | STAINLESS STEEL SCREW M5X12 | 56  | HANDLE               |
| 6   | SCREW M5X12                 | 57  | SCREW M6X40          |
| 7   | SPRING WASHER               | 58  | TAPPING SCREW ST4X14 |
| 8   | SPRING SHEET OF HANDLE      | 59  | SWITCH               |
| 9   | HAND WHEEL                  | 60  | RUBBER RING          |
| 10  | HEXAGON BOLT M6X35          | 61  | PLUG AND CORD        |
| 11  | ROTATION TABLE              | 62  | LEFT HANDLE          |
| 12  | SPRING                      | 63  | HANDLE SUPPORT BOARD |
| 13  | 7 STYLE BLOCK               | 64  | CIRCLIP              |
| 14  | LOCK NUT M6                 | 65  | LOCK PIN             |
| 15  | DOUBLE HEAD SCREW           | 66  | SCREW M5X6           |
| 16  | INDICATOR                   | 67  | CORD                 |
| 17  | SCREW M4X10                 | 68  | CORD CLIP            |
| 18  | NUT M12X100                 | 69  | SCREW M4X10          |
| 19  | LOCK NUT M12                | 70  | CORD PRESSURE BOARD  |
| 20  | SCREW M8X35                 | 71  | SCREW M5X12          |
| 21  | NUT M8                      | 72  | PULL SPRING BAR      |
| 22  | NUT M5                      | 73  | PULL SPRING          |
| 23  | FIXED PIECE                 | 74  | DUST BAG             |
| 24  | PIN                         | 75  | DUST TUBE            |
| 25  | SPRING WASHER               | 76  | BEARING 6202         |
| 26  | SCREW M5X10                 | 77  | ROTOR                |
| 27  | NUT M6                      | 78  | SCREW M5X65          |
| 28  | SPRING WASHER               | 79  | STATOR               |
| 29  | NUT M6X16                   | 80  | BEARING 6200         |
| 30  | BRACKET                     | 81  | WAVE WASHER          |
| 31  | LIMIT BOARD                 | 82  | HOUSING              |
| 32  | RUBBER WASHER               | 83  | REAR COVER           |
| 33  | STOP BAR                    | 84  | SCREW M4X25          |
| 34  |                             | 85  | BRUSH HOLDER         |
| 35  | SPRING WASHER               | 86  | CARBON BRUSH         |
| 36  | SCREW M8X40                 | 87  | SCREW M5X20          |
| 37  | BLOT M8X16                  | 88  | SPRING WASHER        |
| 38  | OUTER FLANGE                | 89  | FLAT WASHER          |
| 39  | INNER FLANGE                | 90  | SCREW                |
| 40  | CIRCLIP FOR HOLE            | 91  | ROTATION PIECE       |
| 41  | BEARING 6203                | 92  | PLASTIC RING         |
| 42  | SPINDLE                     | 93  | BOLT                 |
| 43  | FLAT PIN                    | 94  | WHEEL COVER          |
| 44  | BEARING 6202                | 95  | WHEEL GUARD          |
| 45  | SCREW M6X12                 | 96  | COIL SPRING          |
| 46  | SCREW M8X20                 | 97  | GUARD FIX BOARD      |
| 47  | WHEEL GUARD                 | 98  | SCREW M5X6           |
| 48  | SPRING                      | 99  | CONNECT BAR          |
| 49  | BELT WHEEL                  | 100 | M5 SCREW             |
| 50  | WASHER                      | 5a  | BALL SCREW           |
| 51  | SPRING WASHER               |     |                      |