




MC1200, MC1400 Part list

No.	Part list	No.	Part list
1	Wind guide	35	Inner flange
2	O-ring	36	Seal ring
3	Screw	37	Bearing cover
5	Stator	38	Bush
8	Insulation washer	39	Bearing
9	Bearing	40	Bearing seat
10	Anti-dust cover	41	Big gear
11	Handle cover	42	Bearing
12	Switch cover	43	Guard
14	Switch	44	Pinion gear
15	Spindle	45	Bearing
17	Housing	46	Seal ring
18	Nameplate	47	Washer
19	Tapping screw	48	Key
21	Tapping screw	49	Rotor
22	Washer	50	Screw
23	O-ring	51	Flange screw
28	Tapping screw	52	Out flange
29	Cable clamp	53	Spring pin
30	Cable sleeve	54	base
31	Power cable	55	Socket
32	Brush holder	56	Circlip
33	Carbon brush	57	Wing screw for depth
34	Brush cover		