



PW1900



NO.	DESCRIPTION
A1	CAP
A2	DETERGENT TANK
A3	WATER INLET CONNECTOR&FILTER
A4	BACK HOUSING
A5	WHEEL
A6	MOTOR&PUMP ASSY
A7	WHEEL COVER
A8	GUN HOLDER
A9	CABLE JACKET
A10	CABLE PRESS PLATE
A11	SCREW
A12	POWER CABLE
A13	SWITCH KNOB
A14	FRONT HOUSING
A15	PRESSURE HOSE
A16	CLEANING PIN
A17	BUTTON
A18	FRONT DECORATIVE PLATE
A19	ADJUSTABLE NOZZLE
A20	GUN
A21	HANDLE SLEEVE
A22	HANDLE
A23	SCREW
A24	HOSE HOOK
A25	WARNING LABEL
A26	RATING LABEL
A27	POWER CABLE HOOK
A28	ACCESSORIES HOLD
A29	DETERGENT TUBE

PW1900



NO.	DESCRIPTION	NO.	DESCRIPTION
A2	OIL CYLINDER	A51	CHECKING VALVE CORE
A3	OIL SEAL 30X17X7	A52	CHECKING VALVE BRACKET
A4	BEARING 6302Z	A53	CHECKING VALVE SPRING
A5	GEAR SHAFT	A54	O RING 6X1.8
A6	BIG GEAR	A55	CHECKING VALVE CAP
A7	BEARING 629-2Z	A56	O RING 9.5X1.8
A8	SWASH PLATE	A57	OIL SEAL 10X16X4
A9	GASKET 8	A58	INLET HOSE
A10	BLOT M8X20	A59	O RING 5.5X2
A12	PUMP BODY	A60	U PIN
A13	PUMP COVER	A61	U PIN
A14	PLUNGER OIL SEAL 10X16X4	A62	BOLT M6X8
A15	OIL SEAL BRACKET	A63	O RING 10X2.2
A16	PLUNGER	A64	O RING 58X2
A17	PLUNGER CHUCK	A65	ON-OFF SWITCH ASSY
A18	PLUNGER SPRING	A66	SWITCH-DOWN COVER
A20	OUTLET HOSE	A67	SWITCH WIRE ASSY
A21	O RING 5.5X2	A68	SWITCH WIRE
A23	BAYONET LOCK	A69	FEMALE TERMINAL
A24	O RING 12X2	A70	COVER FOR FEMALE TERMINAL
A25	RELIEF VALVE CORE	A71	MALE TERMINAL
A26	LIMIT RING	A72	COVER FOR MALE TERMINAL
A27	RELIEF VALVE SPRING	A73	COVER FOR OUTLET WIRE
A28	U PIN	A74	COVER FOR SWITCH
A29	RELIEF VALVE CAP	A75	ON-OFF SWITCH(WELDED)
A30	RELIEF VALVE GASKET	A76	ON-OFF SWITCH PUSH ROD
A31	O RING 4.5X1	A77	SWITCH- UP COVER
A32	SIPHON ELBOW	A78	BOLT ST2.9X13
A33	O RING	A79	BEARING 51106
A34	STAINLESS STEEL BALL	A80	SEAL RING
A35	SIPHON SPRING	A81	DAMPING RING
A36	O RING 12X2.5	A82	MOTOR
A37	U PIN	A83	FAN COVER DOWN
A38	O RING	A84	FAN COVER UP
A39	BACK PRESSURE VALVE ASSY	A85	FAN COVER FILTER
A40	BACK PRESSURE VALVE CORE	A86	MAIN SWITCH
A41	BACK PRESSURE VALVE SPRING	A87	SWITCH DRIVING LEVER
A42	O RING 3.5X1.9	A88	O RING 8X2
A43	INLET CHECKING VALVE ASSY	A89	INDUCTANCE ASSY
A44	CHECKING VALVE BRACKET	A90	SWITCH COVER
A45	INLET CHECKING VALVE SEAT	A91	OUTLET WIRE COVER
A46	CHECKING VALVE CORE	A92	BOLT ST3.5 X13F
A47	CHECKING VALVE SPRING	A93	GASKET 6
A48	O RING 6X1.8	A94	BOLT M6X55
A49	OUTLET CHECKING VALVE ASSY	A95	CAPACITOR ASSY
A50	CHECKING VALVE SEAT		