




CS1500

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW M8X16	37	ANGLE BRACKET
2	WASHER	38	NUT
3	OUTER FLANGE	39	SCREW M6X16
4	BLADE	40	SPRING
5	INNER FLANGE	41	WING NUT
6	SPINDLE	42	BEARING 6000Z
7	SCREW M4X10	43	ROTOR
8	BEARING PRESS BOARD	44	BEARING 607Z
9	BEARING 6001Z	45	WIND GUIDE
10	GEAR BOX COVER	46	SCREW ST3.9X65
11	SCREW M4X6	47	WASHER
12	SPANNER	48	STATOR
13	MOVING GUARD	49	BRUSH INSERT PATCH
14	BUSH	50	BEARING BUSH
15	GEAR	51	SCREW ST3.9X18
16	KEY	52	REAR COVER
17	RETAINING RING 12	53	SCREW M5X55
18	NEEDLE BEARING HK0808	54	BRUSH COVER
19	SCREW	55	CARBON BRUSH
20	SMALL IRON PATCH	56	BRUSH HOLDER
21	SPRING	57	HOUSING
22	SCREW M6X20	58	HANDLE
23	FIX GUARD	59	SCREW M5X30
24	SCREW M6X16	60	CAPACITOR
25	RUBBER BLOCK	61	SWITCH
26	WASHER	62	NUT
27	SCREW	63	NUT M5
28	NUT M5	64	CABLE CLAMP
29	SCREW M4X30	65	SCREW ST3.9X14
30	SPRING	66	CABLE SLEEVE
31	SPINDLE LOCK POLE	67	CABLE
32	NUT	68	RETAING PLATE
33	DEPTH BRACKET	69	SPANER M8
34	WASHER	70	RULER
35	DEPTH LOCKING POLE		
36	BASE		